

Paraben's CSI Stick is THE portable cell phone forensic and data gathering tool. Paraben's CSI Stick opens the world of digital forensics to anyone needing to gather forensic grade data from cell phones. The process is simple:

In the field:

- 1 - Select the colored cell phone tip for the cell phone model to be acquired
- 2 - Plug the portable power adapter into the USB end of the CSI Stick
- 3 - Plug the CSI Stick into the cell phone
- 4 - Select the data you wish to extract
- 5 - Push the acquire button and wait for the completion indicator



Back in the lab:

Plug the USB end of the CSI Stick into a PC to be read by Paraben's Device Seizure

Paraben's CSI Stick acquires data that can only be read and analysed in Paraben's Device Seizure or Device Seizure Lite. These advanced forensic analysis tools enable you to view, search, and report on data extracted from handheld devices. The CSI Stick (Ver 1.0) currently supports certain Motorola and Samsung phone models.

**1** Seize Cell Phone

**2** Select and attach the appropriate tip

USB Charger Adapter

Paraben's Remote Charger Requires 2 AA Batteries

STP-MO1-PB : Motorola 1 Tip  
STP-MO2-PB : Motorola 2 Tip  
ST-SM1-PB : Samsung 1 Tip

**3**

Select the data you wish to acquire via the sliding switch on front of the CSI Stick

- Position 1 - Text & Multimedia (Everything in Pos. 2 & 3)
- Position 2 - Text, SMS, Contacts, Call Log
- Position 3 - Multimedia - Images, Movies, ring tones, MP3s
- Position 4 - Physical Phone Image

**4** Connect Charger via USB Adapter

**5** Connect Charger, Adapter, and CSI Stick with corresponding tip to seized Cell Phone. Wait for green lights to stop blinking.

**6** Press the 'Start Acquisition' button on back of CSI Stick

**7**

Disconnect Cell Phone and Charger Components

**Start Button Status Color States**

- No Light = Off, No Status
- Both Blinking Green = Connecting
- One Blinking Green = Working
- Solid Green = Finished Process
- Red = Error

**8** Connect CSI Stick to a PC USB Port via CSI Stick USB interface. CSI Stick will mount like a USB Portable Flash Drive

Go to Step 9

**9** Import Data from CSI Stick to DS Lite or Device Seizure 2.0+

(Paraben's DS Lite 1.0 shown)

For more information visit:  
[www.csistick.com](http://www.csistick.com)